

Instructions for Santa placemat quilted 001

- Set spi to 14-16
- Set longarm to stop at jump stitches
- Load muslin (this fabric will be covered up)
- Then load batting
- Then load the fabric for the front of placemat
- Get pattern ready to stitch
- The pattern will first stitch the line around the outside of the placemat (red). This holds all the layers flat.
- Longarm will pause, at OK machine will move to pattern and stitch all the quilting inside the black line.
- Longarm will pause
- Place your placemat backing fabric, right side down, on top of the placemat. Be sure to cover the red line.
- At ok, Longarm will stitch the black line.
- Now you are done.
- Remove from longarm, cut out on red line, clip corners and turn right side out, slipstitch opening closed and top stitch if wanted.

