

Using Encrypted Patterns in you PVM Software

On the menu at the top of a PVM page, click on **TOOLS**.

Next, click on **OPTIONS**

One the next page, click on the **PATTERN PASSWORD** tab

Enter any machine name—it doesn't matter what.

Enter your Red Key number or your Controller number as the password. (Use the number to which your patterns are encrypted). That number is truncated at the end of your pattern name.

Click on **ADD**

Click on **OK**

This information can also be found on the MENU under HELP/Using the PVM/Displaying PAT files.

Reboot PVM.