

## **Locate your Controller &/or Red Key # for your Statler Stitcher**

Turn on both your Statler Computer AND the Statler Stitcher. You need to be able to take a single stitch from the machine head.

Open Creative Studio software (or Precision Stitch).

Click on Help.

Click on About.

If your machine is old, you may not actually have a red key number, but you will still have a controller number. If your Stitcher is not actually turned on, the controller number field will be displayed with \*\*\*\*\* rather than the number.

Statler Stitcher actually recommends that patterns are encrypted to the Red Key number if possible.